

**STB**  
Used for Set Top Box functions

**TV**  
Controls TV functions

**AV**  
Switches between audio video inputs on your TV

**Number Keys**  
Used for typing in channels numbers and alphabet letters

**Mute**  
Turns volume on/off

**Volume +/-**  
Increases/Decreases volume

**Guide**  
Displays programming guide

**Menu**  
Displays main menu

**OK**  
Press when you want to select a program or highlighted object

**Back**  
Returns your programming back to the previous channel

**Rewind/Play/Pause/Fast Forward/Stop**  
For use with PVR/VOD Functions

**Setup & Shift**  
Used for programming only

**Power**  
Turns components On/Off

**Closed Captioning**  
Enable/Disables Closed Captioning

**Channel +/-**  
Changes channels on the STB

**Page Up/Down**  
Scrolls Up and Down from the current page in the guide

**Info**  
Displays information about current program  
\*When pressed twice, shows additional information

**Arrows**  
Allows you to scroll through the guide and menu

**Exit**  
Exits the guide and menu

**Red/Green/Yellow/ Blue Buttons**  
Only used for menu functions

**Turning ON and OFF Television**  
To turn on TV press TV then **POWER**  
Press STB to control our set top box  
To turn off TV press TV then **POWER**